




# AV Party Rentals

EVERYTHING FROM TEASPOONS TO TENTS - SINCE 1968

## CoolBox Operating Instructions

### THE LCD BUTTON PANEL

The Cool-A-Zone C-100 has a user-friendly and easy-to-use LCD indication panel with one-touch button features for activating, timing, setting, and full control of your C-100. The diagram below outlines what the various buttons and indicators mean. Note that the central area (in white below) is an indication panel, whereas the grey area denotes the buttons.



### INITIAL OPERATION

After ensuring the unit has adequate water for operation and that your CoolBox has been plugged in, turn the CoolBox on by pressing the power button either on the LCD Panel face.

### USING YOUR C-100

1. Power Button: turns the unit ON or OFF.
2. Speed Button: this controls the airflow. There are three Speeds, 1 being the lowest and 3 being the highest. Pressing again will take you up to SPEED 3, then pressing it again will bring you down to SPEED 1. The rate of speed will be reflected on the Airflow Indicator.
3. The Cool Button: switches the CoolBox from COOL to VENTILATION modes. One press will switch between the two functions. The COOL mode will activate the pump and water will be used to evaporatively cool, "whereas" the VENTILATION mode will simply circulate the air and deactivates the pump.
4. The Cool Indicator: When lit, this indicates that the CoolBox is in COOL mode. When unlit, this indicates the CoolBox is in VENTILATION mode.

Visit Our Large Showroom:

23800 Newhall Avenue

Newhall, Ca. 91321

Visit us On The Web:

[www.AVParty.com](http://www.AVParty.com)



Phone: 661-259-2151

818-362-8389

Email:

[client.sales@avparty.com](mailto:client.sales@avparty.com)



# AV Party Rentals

EVERYTHING FROM TEASPOONS TO TENTS - SINCE 1968

5. The Airflow Indicator: The lowest bar indicates SPEED 1, the middle bar indicates SPEED 2, and the highest bar indicates SPEED 3.
6. The Anion Indicator: When lit, the Anion function is ON, when unlit, the Anion function is OFF.
7. Timer Button: Activates the CoolBox TIMER feature, allowing you to either start the unit from a start-up set after a certain number hours or stop the unit after a certain number of hours.
8. Anion Button: Turns the ANION function ON or OFF, as indicated by the Anion Indicator.
9. Remote Receiver LCD: Indicates a command received from the remote control.
10. Low Water Indicator: This warning light will let you know when it is time to refill your CoolBox, and if the water gets too low, a buzzer will sound and the COOL mode will stop. No buzzer will come on if you are in VENTILATION mode.
11. Show Ventilation Indicator: Indicates the level of ventilation being used by the CoolBox.
12. Timer Indicator: When lit, indicates the TIMER function is active.
13. Swing Indicator: When lit, indicates the CoolBox SWING function is active.

## WHAT THE TIMER FUNCTION DOES:

1. Starts your CoolBox cooler automatically after *n* hours from the stand-by state; **OR**,
2. Stops your CoolBox cooler automatically after *n* hours after being turned ON.

**Note: the TIMER function can only be set by the hour.**

## USING THE TIMER:

1. Press the TIMER button.
2. You will notice that the TIMER button begins to flicker & you will see that "H x" appears in the TEMPERATURE display.
3. To increase the number of hours, hit the SPEED button on the panel.
4. You **cannot** set the timer for more than **9 hours**.
5. Once the desired hours are set, **do not press any other buttons**, after 5 seconds the TIMER will activate.

## DISABLING THE TIMER:

1. Press the TIMER button.
2. Set the number of hours to "0"; 3. If you wish, you can also hit the POWER button **while** the TIMER button is flickering.
3. Alternatively, you can hit the POWER button after the TIMER has activated, and then hit the POWER button again.

**When in Stand-By mode, the TIMER function will count down to power ON the CoolBox. If the CoolBox is already on, the TIMER function will count down to turn OFF your CoolBox unit.**

Visit Our Large Showroom:

23800 Newhall Avenue  
Newhall, Ca. 91321

Visit us On The Web:

[www.AVParty.com](http://www.AVParty.com)



Phone: 661-259-2151

818-362-8389

Email:

[client.sales@avparty.com](mailto:client.sales@avparty.com)